

Toevoegingstabel voor TSL olieversteker in :

MOTORCARTER			Vernellingsbakken Tandwielkasten Differentieël <u>zonder slip</u> Hydraulische systemen	
Carter inh./ltr	eerste keer in ml	iedere volgende	Ltr olie toevoeging ml	Ltr olie toevoeging ml
2.00	100.00	60.00	0.60	18
2.25	112.50	67.50	0.70	21
2.50	125.00	75.00	0.80	24
2.75	137.50	82.50	0.90	27
3.00	150.00	90.00	1.00	30
3.25	162.50	97.50	1.10	33
3.50	175.00	105.00	1.20	36
3.75	187.50	112.50	1.30	39
4.00	200.00	120.00	1.40	42
4.25	212.50	127.50	1.50	45
4.50	225.00	135.00	1.60	48
4.75	237.50	142.50	1.70	51
5.00	250.00	150.00	1.80	54
5.25	262.50	157.50	1.90	57
5.50	275.00	165.00	2.00	60
5.75	287.50	172.50	2.10	63
6.00	300.00	180.00	2.20	66
6.50	325.00	195.00	2.30	69
7.00	350.00	210.00	2.40	72
7.50	375.00	225.00	2.50	75
8.00	400.00	240.00	2.60	78
8.50	425.00	255.00	2.80	84
9.00	450.00	270.00		
9.50	475.00	285.00		
10.00	500.00	300.00		
			3.20	96
			3.40	102
			3.60	108
			3.80	114
			4.00	120
			4.50	135
			5.00	150
			5.50	165
			6.00	180
			6.50	195
			7.00	210
			7.50	225
			8.00	240
			8.50	255
			9.00	270
			9.50	285
			10.00	300
			11.00	330
			12.00	360
			13.00	390
			14.00	420
			15.00	450

TOEVOEGING VOOR TWEE-TAKT: 30 ml TSL toevoegen aan 1 liter tweetakt olie .

Handelsonderneming La Re

Al meer dan 15 jaar het gezicht op de TSL Beursstand



Facebook.com/tsllare

Remco Lablans

Schuilhoeve 15

3992 NC Houten

M: 06-55848749 T: 030-6372075

Email: tsllare@gmail.com

Website: www.lare.nl